

NOTE:
THIS CUT-OUT TEMPLATE IS TO BE USED AS A GUIDE TO CUT THE INNER REAR PANEL, PROVIDING AN OPENING FOR THE BASE ACTUATOR MOTOR. THE OUTSIDE REAR PANEL IS NOT NEEDED AND WILL NOT BE RE-INSTALLED. IF PREFERRED, A NEW REAR PANEL WITH THIS CUT-OUT CAN BE PURCHASED FROM ELECTRAFIT.

REAR PANEL CUT-OUT TEMPLATE

1. TAPE TEMPLATE TO REAR PANEL ALIGNING THE BOTTOM EDGE AND SIDES.
2. CENTER TAP AND DRILL (4) 3/8" DIAMETER HOLES AS SHOWN ON THE TEMPLATE.
3. USING A JIG SAW WITH METAL CUTTING BLADE, CUT PANEL FOLLOWING THE TEMPLATE GUIDELINE.

